

Tris-Glycine transmembrane buffer (pH 8.3, $10\times$)

Project number: T670013

Storage conditions: 2-8° C.

Products

This product can be used for Western Blot semi-dry and wet transfer method, the prepared transfer buffer can be stored at $2-8^{\circ}$ C.

Caveat

1. Due to the volatility of methanol, it is recommended to use it now. For your safety and health, please wear a lab coat and disposable gloves.

Procedure

- 1. Before use, take the product out of the refrigerator at $2-8\,^{\circ}\mathrm{C}$ and turn it upside down several times to mix well.
- 2. Method of preparation:

Pure water: Tris-Glycine Transfer Buffer (pH 8.3, $10\times$): methanol = 7:1:2